

Instructions

Tools Needed:

- Tape Measure
- Level
- Straight Edge or Ruler
- Squeegee

Step 1: Prep Your Walls

Using a damp cloth or sponge, clean the surface with warm water and mild soap. Allow the walls to dry for a minimum of 24 hours. While cleaning your wall take the last opportunity to finally check: is this a smooth surface? Orange peel, knockdown or a rough wall will make the peel & stick wallpaper challenges to adhere to the wall, if the surface is not smooth we recommend the conventional commercial wallpaper with paste or wall glue.

Step 2: Plan It Out

Lay panels flat and measure where your panels will be placed.

Step 3: Application

Place the first strip and peel away the paper backing a few inches at a time - from the top of the roll. Support the roll + peel the back of the wallpaper slowly as you go. Align the top of the artwork with the ceiling, making sure it is straight and even on the wall. If you need to adjust the placement, slowly peel the paper off the wall and reapply as necessary. Once the top of the strip is in position, gently peel the paper backing down a foot at a time and smooth the paper onto the wall, moving from the center outwards. If necessary, use the squeegee to smooth air bubbles to the edge of the design, being careful not to damage your artwork. Pick up your second strip and apply it so that the left side aligns the right side of the previous, matching up the design. Repeat this step, moving from left to right and aligning each new strip with the strip to its left.

Step 4: Once you've applied all strips, use a blade to trim any excess paper at the edges of the wall.

WARNING: DO NOT apply wallpaper with wet hands or sponge.

DO NOT use dull scissors/blade if cutting wallpaper. **NOT** recommended for areas that reach 50% humidity or higher. **DO NOT** place wallpaper in an area likely to have steam or heat, like a Kitchen or Bathroom as it is likely to cause issues, such as peeling. Buyer assumes risk that damage may occur during install and/or removal, dealer/supplier is not responsible for any damage.

SURFACES **NOT** RECOMMENDED FOR APPLICATION:

Textured/Uneven Walls
Dark/Multi-colored walls
Wallpapered walls
Brick/Cinder block
Unpainted Drywall/Sheetrock or Plaster
Outdoors
Non-stick Paint

Removal: Starting in the top left corner, pry up wallpaper gently with a putty knife. Once it starts to come up, peel very slowly at a 45° angle and at a constant speed. Do not pull straight or yank it fast, this could damage the wall. If necessary, use a heat gun to warm the adhesive as you pull. **WARNING:** Damage may occur when removing such as paint or drywall. Buyer assumes risk that damage may occur during install and/or removal, dealer/supplier is not responsible for any damage.